POCKETALK QUICK START GUIDE

STEP**1**

Press the ⌄ **button.**

STEP**2**

Speak while pressing the ⌄ **button.**

↓ Mic. ↓

話してください
please talk

↑ Mic ↑

STEP**3**

Once you've finished speaking, let go of the ⌄ **button.**

このミュージアム
ショップで、免税品
を買うことはできま
すか？

Is it possible to buy
things duty-free here at
the museum shop?

Pocketalk automatically detects which of the two languages is being spoken, but to change these languages, simply tap on the language name and select the desired language from the list.

English(US)

日本語

〈 OK   言語

英語(米国) (English(US)) ✓
英語(ゆっくり) (English(slow…
英語(英国) (English(UK))
英語(インド) (English(India))
英語(オーストラリア) (Eng

You can also select the language by voice by speaking the language name while holding down the ⌄ **button.**

From the launcher icon in the upper left corner of the screen, you can select translation history, camera translation, unit conversion, etc.

A   B   C

Español
Spanish(Spain)

English(US)

D   E

Settings   Camera

History   F   Convert Units

Home Screen   **Launcher Screen**

A. Launcher

B. History
   (Swipe down)

C. Camera Translation
   (Pre-setting required)

D. Back to Home

E. Status

F. Other Features

Online User Guide

Online Store

POCKETALK

Tips for Speaking

Speak loud and clear
Speaking clearly improves translation accuracy dramatically.

Do not omit the subject
Always include the subject (I, you, he, she, it, we, they).

Avoid inversion
Subject-Verb-Object (e.g., I eat an apple)

Keep it longer
Speak in longer sentences for better accuracy.

Break sentences with a pause
Pause clearly between sentences.

Speak into the mic
Speak directly into the microphones at the top or bottom of the device.

Useful Functions

Favorites
Save frequently used phrases.

1. Turn on history saving. (Tap "Settings" on the launcher screen, then tap "Save History".)
2. Tap ▭ on the home screen.
3. Long press or swipe right on the history you want to register.
4. Tap the ★ button on the home screen.

Delete History Automatically
Protect customer data.

1. Go to the launcher screen and tap "Settings". Then, tap "Save History".
2. Enable "Save History", then enable "Auto-delete history".
3. Set the time interval for automatic deletion (e.g., 60 minutes)
4. History will be automatically deleted after the specified time interval.

Translate into other Languages
Re-translate into other languages

1. Tap the ⋮ on the translation result screen.
2. Tap "Translate into other Languages".
3. Select the language you want to translate into and tap "OK"

Change Lang. (Voice)
Quickly change languages with voice command..

1. Tap the language you want to change on the home screen.
2. Say the name of the language while holding down ⟳ button.
3. Tap ‹OK in the upper left corner.

Change Lang. (Flag)
Unsure of their language? Ask them to choose a flag

1. Tap the language you want to change on the home screen.
2. Tap the ◼ button in the upper right corner.
3. Ask your conversation partner to choose his/her flag and language.

Unit Conversion
Convert various units and currencies with latest rates.

1. Tap "Unit Conversion" on the launcher screen.
2. Select the currency (e.g., JPY) and enter the amount.

   *This function can also convert length, weight, and temperature.