# **POCKETALK S2 Series QUICK GUIDE**

STEP1

Press the v button.

STEP2

Speak while pressing the button.

STEP3

When you have finished speaking, release your finger from the button.







Tap the language name to change the language.

Speak in either language. It'll automatically detect and translate.





You can also select a language by voice by speaking the language name while holding down the button.

From the launcher icon in the upper left corner of the screen, you can select interpretation history, camera translation, unit conversion, etc.



Home Launcher

- A. Launcher
- B. History (Swipe down)
- C. Camera Translation (Pre-setting required)
- D. Back to Home
- E. Status
- F. Other Features



Online User Guide



Online Store

# **Tips for Speaking**



### Smooth and clear

Clear speech is vital for accurate Al interpretation.



## Keep it longer

Speak in longer sentences for better accuracy.



### Do not omit the subject

Always include a subject (I, you, he, she, it, we, they).



### Break off a sentence

Pause clearly between sentences.



### **Avoid inversion**

Subject-Verb-Object (e.g., I eat an apple)



## Speak to the mic

Speak directly into the microphones at the bottom of the device.

# **Useful Functions**



- Turn on history saving. (Tap "Settings" on the launcher screen, then tap "Save History".)
- 2. Tap on the home screen.
- 3. Long press or swipe right on the history you want to register.
- 4. Tap the **\*** button on the home screen.



### Delete History Automatically

Protect customer data.

- Go to the launcher screen and tap "Settings". Then, tap "Save History".
- 2. Enable "Save History", then enable "Auto-delete history".
- 3. Set the time interval for automatic deletion (e.g., 60 minutes)
- 4. History will be automatically deleted after the specified time interval



# Translate into other Languages

Re-translate into other language

- 1. Tap the on the translation result screen.
- 2. Tap "Translate into other Languages".
- 3. Select the language you want to translate into and tap "OK"



## Change Lang. (Voice)

Quickly change languages by voice while using the device.

- 1. Tap the language you want to change on the home screen.
- 2. Say the name of the language while holding down w button.
- 3. Tap **<OK** in the upper left corner.



#### Change Lang. (Flag)

Unsure of their language? Ask them to choose a flag

- 1. Tap the language you want to change on the home screen.
- 2. Tap the button in the upper right corner.
- 3. Ask your conversation partner to choose his/her flag and language.



### **Unit Conversion**

Tell the amount in the customer's currency.

- 1. Tap "Unit Conversion" on the launcher screen.
- 2. Select the currency (e.g., JPY) and enter the amount.
  - \*This function can also convert length, weight, and temperature.



#### **Security on Pocketalk**

All conversation contents via Pocketalk are encrypted. In addition, the content of conversations (voice data and text data) captured to provide this service is designed to be deleted immediately after processing. Furthermore, unlike other similar services, neither Pocketalk nor its partners (all providers of speech recognition, translation, cloud services, etc.) will view, use, or analyze the content of your conversations without your consent, nor will it be used to train Al (artificial intelligence).